

FITTING INSTRUCTIONS

Fitting List

- 1 x Anti Siphon Device (supplied)
- 4 x Grub Screws (supplied)
- 1 x Sleeve (supplied)
- 1 x Drift
- 1 x Hammer
- 1 x 3mm Allen Key
- Loctite (Optional)


Step 1



Step 2



Step 3



Step 4



Step 1: Remove all internal fittings such as filter or indicator.

Step 2: Insert Anti Siphon Device and screw in the supplied grub screws (4) ensuring that the device is evenly spaced. Use **Loctite** to secure screws (optional).

NOTE: Please ensure that the grub screws are fully inserted. Failure to do so will damage the sleeve when fitting

Step 3: Place sleeve into the device ensuring that it sits level.

Step 4: With a drift and hammer secure the sleeve into the device ensuring that it remains level to reduce any damage.